



Fig. 10 Fuel supplying system

Fig. No.	Ser No.	Fig./Ser. No.	Part No.	Name of Part	Qty.
10	1	F10S1	Y380-10100	Fuel injection pump assy.	1
10	2	F10S2	Y480G-10200-1	High pressure fuel pipe(I)	1
10	3	F10S3	P662-00MX	Injector assy.	3
10	4	F10S4	Y385T-1-10400	Return pipe	1
10	5	F10S5	480G-10200-2	High pressure fuel pipe(II)	1
10	6	F10S6	Y385T-1-10700	Fuel pipe (metal)	1
10	7	F10S7	CX0706-P	Fuel filter seat	1
10	8	F10S8	CX0706	Fuel filter (spin-on)	1
10	9	F10S9	Y385T-1-10600	Fuel pipe (metal)	1
10	10	F10S10	180.50.020	Fuel pipe	1
10	11	F10S11	180.50.030	Sediment cup assy.	1
10	12	F10S12	180.50.201	Gasket	1
10	13	F10S13	TY290X.02.160	Hand pump assy.	1
10	14	F10S14	CX0706A	Fuel filter assy(spinner)	1
10	15	F10S15	180.50.202	Washer	6
10	16	F10S16	C0506A-0009	Pipe connection bolt	1
10	17	F10S17	TAX-0011	Fule pipe screw	1
10	18	F10S18	TAX-0012	Screen Bolt	1
10	19	F10S19	TAX-0902	Overflow valve body	1
10	20	F10S20	TAX-0010	Intake fuel pipe screw	1
10	21	F10S21	TS4100.19.111	Fuel return connection screw	3
10	22	F10S22	C0506A-0006	Pipe connection bolt	1
10	23	F10S23	180.50.203A	Wsher	8
10	24	F10S24	180.50.204A	Bolt	3
10	25	F10S25	480G-10200-3	High pressure fuel pipe(III)	1
10	26	F10S25	180.50.203B	Washer	4